

DS-6 Config

DS-6-Config has been designed to build and maintain DS-6 systems. It shall help to automate many steps, which otherwise must be done manual. To achieve this aim, the following functions were implemented:

- creating and managing directory structures
- configuration versioning
- reading, creating and modifying configuration files, which contain the configuration of all devices of the whole DS-6 system. Its format is a comma separated list of values.
- comparison of the devices from the DS-6 configuration list with this one of a real DS-6 system
- configuration of the devices with a new or a modified DS-6 configuration list
- configuration of DS-6 I/O-Modules with a program and the related parameters



DS-6 Config
Art.-No. 5 009 4

Requirements

- A conventional PC (Microsoft Windows XP or above) is needed