

TIMM SIP-Trunk

The TIMM SIP Trunk software, which is an extra software package that complements the TIMM ComServer, is required to connect the TIMM system to IP PBX telephone systems. (The abbreviation IP PBX stands for **I**nternet **P**rotocol **P**rivate **B**ranch **E**xchange.) The term “IP PBX telephone systems” refers to largely software-based in-house telephone networks that use the Internet protocol and that provide a large number of common services supplied by former telecommunication systems. The TIMM SIP Trunk software allows the TIMM ComServer to communicate with IP PBX telephone systems by means of the SIP Trunk protocol.

TIMM SIP-Trunk
Art.-No. 5 065 6

Requirements

- TIMM ComServer (Art.-No. 3 353 4) required inside the TIMM System